

STANDARD & DELUXE RADIOLOGICAL TESTING SAMPLING INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS COMPLETELY BEFORE COLLECTING YOUR WATER SAMPLE

One test kit represents one sampling location. If you require testing on multiple locations you will need to purchase multiple test kits.

1. Remove aerators, strainers, mixers or purifiers from your tap.
2. Run the cold water for approximately 3-5 minutes, then adjust the flow to a thin stream to avoid splashing or overfilling.
3. Fill all the bottles to the neck, cap securely and return to the shipping container.
4. Complete the enclosed lab form, **making sure to indicate the date and time you sampled**, type of water (treated/untreated) and sample identification which identifies where you collected your sample (i.e., kitchen sink, well head, etc.). Retain a copy of the lab form for your records and return the completed form to the shipping container.
5. Mail your sample to the testing location below. The sample can be sent 2-3 day delivery.

Testing Location: **National Testing Laboratories, Ltd.
556 South Mansfield Street
Ypsilanti, MI 48197**

6. There is a separate box which contains the bottle for the radon analysis. Follow the instructions contained in the box and ship to the location specified by the prepaid shipping label. ***The radon testing is performed at another location and should be sent to:***

Radon Diagnostic Laboratories
P.O. Box 1507, 3100 Hotel Road
Auburn, ME 04211-1507

7. PLEASE NOTE: Testing takes approximately 10-14 business days from receipt of the samples. Results can be emailed or faxed (if provided an email address or fax number).

If you have any questions regarding this Standard or Deluxe Radiological Test or any other services we provide, please contact a Technical Service Representative at National Testing Laboratories at 1-800-458-3330 for assistance.

Thank you for choosing National Testing Laboratories, Ltd., for your water testing services!